



EMBUDO PARA ACEITE UNIVERSAL CON ABRAZADERA Y ROSCA 647-1270FC

DESCRIPCIÓN

Herramienta ideal para llenar sistemas de lubricación como motor y transmisiones, con este equipo puedes hacer un proceso profesional, rápido y sencillo sin derrames y sin hacer operaciones NO profesionales (adaptaciones o injertos) los cuales causan desperdicios de lubricantes, esto facilita la operación para el técnico y de igual manera puedes mejorar tu productividad realizando procesos en menos tiempo y aumentar tus ingresos.

CARACTERÍSTICAS

- Embudo de llenado de aceite del motor con 0% de fugas y evitar salpicaduras y derrames de aceite en el motor, bloque o culata.
- Se puede aplicar a casi todos los automóviles, ya que tiene una rosca de tipo roscado y una abrazadera para cada tamaño de agujero.
- Longitud total del embudo: 254.5 mm / 10.0 in
- Longitud de la cámara: 74.5 mm / 2.9 in
- Adaptador cónico: 56 mm / 2.2in
- Hilos adaptadores cónicos: M34.2 * P1.75
- Ancho de apertura del embudo: Φ 125mm / 4.9in
- Abertura del paso de aceite: Φ 21mm / 0.8in
- Tamaño del círculo: Φ 45mm / 1.8in
- Hilos circulares: M34.2 * P1.75
- Paso (solo tipo roscado): 3.5P y 3 OP
- Rango de apertura: aprox. Φ 29-74mm / 1.1 * 2.9in




Imagen de referencia sujeta a cambio de diseño



WARNING:

- ALWAYS WEAR GLOVES WHEN USING THIS TOOL.
- ALWAYS WEAR EYE PROTECTION THAT MEETS OSHA/ANSI Z87.1 STANDARDS.
- ALWAYS KEEP WORKING AREA CLEAN AND FREE OF OIL SPILLS ON FLOOR.

- Thread funnel into the clamp ring(Fig.1).
- Insert the clamp opening into oil filler neck.The opening will be automatically adjusted to the width of the filler neck(Fig.2).
- Start refilling the oil into the engine(Fig.3).
Use the other hand to hold the funnel set while refilling(clamp-on type only).



HOW TO ADJUST THE CLAMP RING?

NOTE The height of clamp ring should only be adjusted when using with a regular funnel



Release the screw anti-clockwise.

Adjust the clamp ring.

Fix the screw clockwise.

- Clamp works with regular funnels
- Regular funnel is not included in this set

Nombre Cliente: _____

Nit: _____

Firma: _____

Carrera 2 Norte No. 17-97 Ejenexos Bodega SM4 / Teléfonos: 3541173 Ext. 112
Dosquebradas – Risaralda - Colombia - Email: soporte@tecnotalleres.com